

SHORT FORM SERVICE MANUAL - CIM 5 CONTROLLER



SHORT FORM SERVICE MANUAL



Operating temperature

- ① : -30°C to +30°C
: -22 F to +86 F

Ambient temperature

- ② : -30°C to +50°C
: -22 F to +122 F

Model: SC-MCI40-WC, SC-MCI40, SCI-40 and SCU-40

Refrigerant: R-134a

Charged with 4.5 kg / 9.9 lb

STAR❄️COOL




SHORT FORM SERVICE MANUAL



Controller box view

- ① Phase direction
- ② Phase direction
- ③ Heat element
- ④ Cond. fan low
- ⑤ Cond. fan high
- ⑥ Evap. fan low
- ⑦ Evap. fan high
- ⑧ FC/Compressor
- ⑨ Main circuit breaker




SHORT FORM SERVICE MANUAL



Controller box view

- ① Terminal block PCB
- ② Power meas
- ③ Power in
- ④ Modem (if installed)
- ⑤ Transformer




SHORT FORM SERVICE MANUAL



Controller box view

- ① Controller connections
- ② Fuses: 2x 0.4/0.63 Amp.
3x 10 Amp.
- ③ Fuse: 6.3 Amp.

Recommended to raise
F1 and F2 to 0.63 Amp.




SHORT FORM SERVICE MANUAL



Unit rear side view

- ① Tsuc sensor
- ② Return air sensor
- ③ Humidity sensor
- ④ Evaporator sensor
- ⑤ Supply air sensors





Replacement of Tsuc sensor


- ① : Remove PVC Cover to access Tsuc sensor
- ② : Cut cable tie (one pcs). Sensor can then be removed
- ③ : When installing the new sensor, make sure to insert properly in tube





Replacement of air exchange sensor

- ① : Remove the two finger screws on the butter fly and remove cover plate
- ② : Remove the fourteen screws to loosen the black cover where the air ex-sensor is mounted
- ③ : Replace the sensor and install all the dismantled parts again



SHORT FORM SERVICE MANUAL



Air exchange sensor calibration

- ① Close fresh air butterfly
- ② In the service menu SO5; Configuration menu FO6; Press "Enter" twice
- Calibration is completed





SHORT FORM SERVICE MANUAL



Supply voltage measurements

- ① Measure voltage output from the main circuit breaker
 - ② Measure voltage supplied to the power meas PCB
- Range -50 Hz: 335 – 460 VAC
Range -60 Hz: 390 – 525 VAC



SHORT FORM SERVICE MANUAL




Supply voltage measurements

- 1 Measure the voltage output from the power meas PCB to the main circuit

Range -50 Hz: 335 – 460 VAC

Range -60 Hz: 390 – 525 VAC



SHORT FORM SERVICE MANUAL



Supply voltage measurements

- 1 Measure the voltage output from the power meas PCB to the transformer

Range -50 Hz: 335 – 460 VAC

Range -60 Hz: 390 – 525 VAC




SHORT FORM SERVICE MANUAL



Supply voltage measurements



- ① Measure the voltage supplied to the transformer
 - Range -50 Hz: 335 – 460 VAC
 - Range -60 Hz: 390 – 525 VAC





Supply voltage measurements

- ① Measure the voltage output of the transformer 20 VAC
- ② The output voltage depends on the supply voltage
Range: 15.3 – 24.3 VAC




SHORT FORM SERVICE MANUAL



Supply voltage measurements

- ① Measure the voltage output from the transformer 24 VAC
- ② The output voltage depends on the supply voltage
Range: 18.9 – 30.0 VAC





Check of 6,3 Amp fuse

Measure voltage from GND to top of fuse

- ① Fuse is ok
Range 18.9 - 30 VAC
- ② Fuse is not ok



SHORT FORM SERVICE MANUAL



Check power to ON/OFF PCB

- ① Measuring from ground to terminal 4 (see picture) shows that the controller is turned OFF
- ② After turning ON, the voltage can be measured
Range 18.9 – 30.0 VAC





Check power to ON/OFF PCB

- 1 After turning ON you can read the voltage supplied through the "ON/OFF" PCB on terminal 1 and 2
Range 15.3 – 24.3 VAC





Check Frequency Converter

- 1 Frequency converter MUST always have the black foil mounted for protection of print, components and your safety

WARNING - HIGH VOLTAGE





Check Frequency Converter

- ① If deviation between phases is more than 15 VAC:

Alarm "523 FC phase loss" or
Alarm "516 FC Trip phase loss"
will be given

Range -50 Hz: 335 – 460 VAC
Range -60 Hz: 390 – 525 VAC


E.g. due to unstable power supply
from the genset





Check Frequency Converter

- ① A green light indicates FC is ok
- A flashing green light indicates FC communicates with the controller
- ② A red light indicates a problem






Check Frequency Converter

- 1 If a red light is ON and alarm 500 "FC missing" is displayed, the FC has an internal problem and must be replaced

The "Warrenty repair report" must be filled out and submitted to Star Cool. The defect part must be properly tagged





Emergency operation

- 1 Dismount the frequency converter and connect the FC power 1 cable directly to the compressor supply terminals (W, V, U)

The 3 remaining terminals (Y, X, Z) have to be fitted with a wire-jumper.



SHORT FORM SERVICE MANUAL



Emergency operation

- 1 Go to Service menu and select "Configuration" (S05)

In "Configuration" menu scroll down to "FC type" (F03)

Then press return and select "NONE"

Note: remember to switch back to "Danfoss" in the "FC type" setting when a new FC is mounted






Contactor check

- ① Measure Ω between terminal A1 and A2
- ② Contactor is ok
- ③ Contactor is not ok

Deviation in resistance due to change in temperature

STAR❄️COOL






Temperature sensor check

- 1 Disconnect X1 on the controller door

All temperature readings must drop to -70°C within approximately 5-10 minutes

If one or more temperatures do not drop to -70°C , the controller must be replaced

The "Warrenty repair report" must be filled out and submitted to Star Cool. The defect part must be properly tagged





Temperature sensor check

Dismount the current defect sensor(s) according to the wiring diagram inside the controller door



SHORT FORM SERVICE MANUAL



Temperature sensor check

- 1 Measure the voltage between the two terminals on the PCB
Correct range: $4.80 > 5.05$ VDC





Temperature sensor check

- ① Measure the resistance of the disconnected sensor
- Value must be according to the resistance table in the "Operation and Service manual"
- E.g. $32.65\text{ k}\Omega = 0^{\circ}\text{C} / 32\text{ F}$





Temperature sensor check

- 1 Place the bulb in ice-water and stir the sensor in the ice-water

The displayed temperature in the controller should be: 0°C $\pm 0.5^{\circ}\text{C}$ ($32^{\circ}\text{F} \pm 1.25^{\circ}\text{F}$) otherwise replace the sensor





Pressure transmitter check

- 1 Disconnect X1 on the controller door


Psuc (and Peco) value must go to 14.7 or 12.0 Bar

Pdis value must go to 45.0 or 32.0 Bar

Values depends on transmitter type configured in configuration menu menu (FO7 and FO8) (NSK, AKS)

If the above mentioned values are not reached within 5-10 minutes, the controller module must be replaced

The "Warrenty repair report" must be filled out and submitted to Star Cool. The defect part must be properly tagged





Pressure transmitter check



- 1 Dismount the current defect transmitter according to the wiring diagram inside the controller door





Pressure transmitter check


- ① Measure voltage between GND and 5 VDC for the transmitter.
(According to the electrical wiring diagram)
- ② Correct range:
 $4.80 > 5.05$ VDC





Pressure transmitter check


- ① Reconnect GND and 5 VDC wires for the transmitter
- Measure voltage between signal wire and GND
- ② Check signal output from transmitter. Compare it to gauge reading/value found in relevant table in the "Operational and Service manual".





Check of heat elements

- 1 Measure the voltage (across each heater pair)
- 2 Measure the resistance value of each disconnected heater:
210 Ω (105 Ω as a pair)
Value for tray heater: 400 Ω
Range: +/- 10 Ω




SHORT FORM SERVICE MANUAL



Change of parts

- 1 Always make sure to turn OFF the main circuit breaker and disconnect the power cable



SHORT FORM SERVICE MANUAL



Contacts

Internet

www.starcool.dk

Spare parts / orders

sales@starcool.dk

Service

service@starcool.dk

Logistic

logistics@starcool.dk

Technical Hot line 24/7

+45 73 64 35 00